



THIS REPAIR KIT WILL FIT ALL CONTINENTAL VALVES LISTED BELOW:

A-211	A-212	A-213	A-214
A-1201	A-1202	A-1204	A-1205
A-1206	A-1250	A-1275	A-1285
A-1350	A-1375	A-1385	

**NOTE:** WHEN REPLACING TEFLON STEM PACKING BE SURE TO REMOVE ALL BURRS AND SHARP EDGES FROM STEM. AN OVERSITE OF THIS PROCEDURE MAY DAMAGE THE NEW "V" RING PACKING.

**CAUTION:** BEFORE REPAIRING VALVES, MAKE SURE ALL ANHYDROUS AMMONIA AND ADDITIVES ARE COMPLETELY EVACUATED.

# BONNET & STEM REPAIR PARTS

